


Agencourt RNAdvance Blood Kit for Micro RNA and Total RNA Isolation from 200 μ L of Plasma and Serum

SUPPLEMENTAL PROTOCOL



Bee Na Lee, Ph.D. Staff Application Scientist, Beckman Coulter Life Sciences

Process Overview



Introduction

The Agencourt RNAdvance Blood RNA purification kit utilizes Beckman Coulter's Agencourt SPRI paramagnetic bead-based technology to isolate total RNA from PAXgene preserved blood. The protocol is modified to isolate micro RNA (miRNA) and total RNA from 200 μ L of plasma or serum per well in 96-well or 2 mL tube formats.

Notice for miRNA and total RNA Isolation

If the RNAdvance Blood Kit is to be used for miRNA and total RNA isolation:

- **100% Isopropanol must not be added directly to the Wash Buffer bottle.** See Reagent Preparation step 2 for Wash Buffer preparation.
- 500 μ L of Isopropanol is added in the BindI at step 4 instead of 400 μ L (see Reagent Preparation step 3).
- 75% ethanol should be used instead of 70% ethanol in all ethanol washes.

Warnings and Precautions

Please refer to the RNAdvance Blood kit protocol, B66715, at www.beckmancoulter.com/ifu.

General Remarks on Handling RNA

RNases are ubiquitous and general precautions should be followed in order to avoid their introduction to your sample during the RNAdvance Blood kit extraction procedure. The most common sources of RNase contamination are hands, dust particles, and contaminated laboratory instruments, solutions and glassware. When working with RNA, the following procedures should be used to limit RNase contamination:

- Always work with gloved hands and change gloves frequently.
- Use RNase-free, filtered pipette tips for pipetting whenever possible.

- Use dedicated RNase-free equipment (e.g. pipettes, pipette tips, gels boxes, etc.)
- Avoid using reagents, consumables and equipment that are shared for other general lab processes.
- When available, work in a separate room, fume hood or lab space.
- Use plastic, disposable consumables that are certified RNase-free.
- Purchase reagents, such as commonly used buffers and water, that are certified RNase-free.
- Prepare small individual aliquots of such buffers to avoid repeated transfer out of stock buffers. This lowers the risk of contaminating the stock solution.
- Wipe down work surfaces with commercial RNase-inhibiting surfactant solutions or 85% ethanol before starting work.

Materials Supplied by the User

Consumables and Hardware:

- Agencourt SPRIPlate 96R – Ring Super Magnet Plate (Beckman Coulter Life Sciences, A32782) or Agencourt SPRISStand – Magentic 6-tube Stand (for 1.7 mL tubes) (Beckman Coulter Life Sciences, A29182)
- 1.7 mL microcentrifuge tubes (Fisher Scientific, NC9448938) for tube format
- 96-Well Riplate-2.2mL (Ritter Medical, 43001-0200) for plate format
- 1.2 mL 96-well plate (ABGene #AB-1127; <http://www.abgene.com>)
- 37°C, 55°C and 85°C water bath or heat block for proteinase K digestion and DNase treatment
- Plate Seals (ABGene #0580; <http://www.abgene.com>)

Reagents:

- 100% Isopropanol; American Bioanalytical AB07015 or equivalent
- 75% ethanol; freshly prepared/diluted from 100% ethanol (American Bioanalytical, AB00138 or equivalent)
- Reagent grade water; nuclease-free; Ambion AM9932

Reagent Preparation

Prepare the following reagents in advance for both the 96-well and 2 mL tube protocols:

- I. Add PK Buffer to the Proteinase K tube/bottle** (final concentration is 50mg/mL):
 - For the 50 prep kit, add 1.2 mL of PK Buffer per tube of Proteinase K.
 - For the 384 prep kit, add 10 mL of PK Buffer to the bottle of Proteinase K.
 - Mix components by inverting the tube/bottle several times. To avoid foaming, do not vortex. The solution will appear cloudy immediately after mixing - let the solution sit for 5 minutes to clear prior to using. **Store the Proteinase K solution at -20°C when not in use.**

- 2. Prepare Wash Buffer:**

- **For miRNA and total RNA isolation:** Add 100% Isopropanol to the Wash Buffer in a proportion of 1:1 (Isopropanol: Wash Buffer). **Example:** To make 10 mL of Wash Buffer solution, add 5 mL of 100% Isopropanol with 5 mL of Wash Buffer in a 15 mL conical tube, and vortex thoroughly for 10 sec.
- **For total RNA isolation only:** Add 100% Isopropanol to the Wash Buffer in a proportion of 1: 1.5 (Isopropanol: Wash Buffer). **Example:** To make 10 mL of Wash Buffer solution, add 4 mL of 100% Isopropanol with 6 mL of Wash Buffer in a 15 mL conical tube, and vortex thoroughly for 10 sec.

- 3. Prepare Bind I/Isopropanol Solution:**

- Shake the Bind I Bottle vigorously to resuspend magnetic particles before aspirating.
- Prepare this solution fresh and per isolation – use within 15 minutes. Discard any unused solution.
- 510 µL of Bind I/Isopropanol Solution is required per sample. Vortex the tube/bottle containing the Bind I Buffer for at least 30 seconds to fully resuspend the beads. Combine 10 µL of Bind I Buffer with 500 µL 100% isopropanol and mix thoroughly.

- 4. Prepare Lysis/PK Solution –** (use within 15 minutes and discard any unused solution):

- For each sample, combine 20 µL PK with 300 µL of Lysis Buffer. **Example:** For ten isolations mix 3.0 mL of Lysis with 200 µL of proteinase K. (It is generally recommended to prepare an additional 10% to account for dead volume.)
- **Note:** Pipette enzyme directly into the liquid and pipette mix up and down to remove any residual enzyme from the inside of the tip. A light vortex can be done to ensure homogeneity, but avoid foaming.

Plasma and serum miRNA Isolation Procedure

1. Aliquot 200 µL of plasma or serum into each well of a 2.2 mL processing plate or 1.7mL tube.
2. Add 320 µL of Lysis/PK Solution (see Reagent Preparation, step 4) to each sample, either in a tube or 96-well plate. Gently pipette tip mix 10 times at the bottom of the well to resuspend the sample mix.
3. Seal the plate with a plate seal. Incubate the samples for 15 minutes at 55°C to complete the lysis and digestion.

Before proceeding to the next step, let the samples cool for 2 minutes to room temperature.

Note: When using this plate in conjunction with a water bath, make sure the plate does not tip over and the seal does not get wet. Should the seal get wet or condensation form on the seal, spin the liquid down and very carefully remove the seal.

4. Prepare Bind I/Isoopropanol Solution as described in Reagent Preparation, step 3. Add 510 µL of Bind I/Isoopropanol Solution to the samples and pipette mix 10 times. Incubate samples at room temperature for 5 minutes.
5. Place the 2.2 mL processing plate on an Agencourt SPRIPlate 96R –Ring Super Magnet Plate (or place 1.7mL tubes on SPRITstand) and separate for 15 minutes, or wait for the solution to turn completely clear.
6. Fully remove supernatant from the 2.2 mL processing plate (or the 1.7mL tube) and discard.

This step must be performed while the 2.2 mL processing plate is situated on the magnet.

7. Remove the 2.2 mL processing plate (or the 1.7mL tube) from the magnet and wash the beads by adding 800 µL of Wash Buffer. Pipette mix for 10 times. (See Reagent Preparation, step2).

Pipette mix 10 times to re-suspend the magnetic beads.

8. Transfer the suspension to a 1.2 mL processing plate. Be sure to transfer all of the sample solution and magnetic beads to the new plate. (Skip this step if using tube format.)

Transferring the samples to the smaller plate allows for easier pipetting in subsequent steps.

9. Place the 1.2 mL processing plate (or the 1.7mL tube) on

the magnet and separate for 7 minutes, or wait for the solution to turn completely clear.

10. Completely remove the supernatant from the 1.2 mL processing plate (or 1.7mL tube) and discard.

This step must be performed while the plate is situated on the magnet. Do not to disturb the ring of separated magnetic beads.

11. Remove the 1.2 mL processing plate (or the 1.7mL tube) from the magnet and add 800 µL of 75% ethanol. Pipette mix 10 times to re-suspend the magnetic beads.

12. Return the 1.2 mL processing plate (or the 1.7mL tube) to the magnet for 5 minutes, or wait for the solution to turn completely clear. Remove the supernatant and discard.

13. Repeat steps 11 and 12 two more times for a total of three 75% ethanol washes.

14. Remove as much ethanol as possible and allow the magnetic beads to dry for 5 minutes at room temperature.

Beads do not need to be completely dry, but the traces of liquid should be gone (i.e. droplets or puddles).

15. Remove 1.2 mL processing plate (or 1.7mL tube) from the magnet and elute RNA by adding of 40 µL of nuclease free water. Pipette mix 10 times and incubate at RT for 2 minutes.

Optional: Remove the 1.2 mL processing plate (or the 1.7mL tube) from the magnet and elute RNA by adding of 40 µL of nuclease-free water. Pipette the mix 10 times and incubate at 85°C for 10 minutes. (Skip Step 17 if elution incubation was performed at 85°C).

16. Return the plate to the magnet for 2 minutes and carefully transfer eluted RNA away from the beads and into a fresh plate or tube and store samples at -80°C.

17. Incubate the eluted RNA at 85°C for 10 min and store the samples at -80°C.

Warranty Disclaimer

Beckman Coulter makes no warranties of any kind whatsoever express or implied, with respect to the method, including but not limited to warranties of fitness for a particular purpose or merchantability or that the method is non-infringing. All other warranties are expressly disclaimed. Your use of the method is solely at your own risk, without recourse to Beckman Coulter.



© 2015 Beckman Coulter Life Sciences. All rights reserved. Beckman Coulter, the stylized logo, Agencourt, RNAdvance Blood, SPRIPlate and SPRI are registered trademarks of Beckman Coulter, Inc. and are registered in the USPTO. All other trademarks are the property of their respective owners. The Agencourt RNAdvance Blood kit is not intended or validated for use in the diagnosis of disease or other conditions.

For Beckman Coulter's worldwide office locations and phone numbers, please visit "Contact Us" at beckmancoulter.com
AAG-1021SP08.15-A